



USING A KITE IS DANGEROUS AND CAN CAUSE SEVERE INJURIES.
BEFORE USE, CAREFULLY READ THIS MANUAL.



RELEASE OF LIABILITY

By assembling or using this CrazyFly kiteboarding product (further named only as product), you agree that you have read and understood the CrazyFly kiteboarding manual (further named only as manual) before using this product. You also agree that you will ensure any other user of this product to read and understand this manual before allowing this person to use this product.

ASSUMPTION OF RISK

Using this product involves certain inherent risks, dangers and hazards, and can cause severe injuries, damage, or death to both the user and to nonuser third party. The user of this product assumes and accepts any and all risks related to the usage of this product. The risk of using this product can be greatly reduced by acquiring training lessons in an accredited kiteboarding school, following the guideline principals of this manual and by using common sense.

FOR YOUR SAFETY AND THE SAFETY OF OTHERS:

- We strongly advice every user of this equipment to take professional lessons in an accredited kitesurfing school.
- Always be extremely careful when using this equipment.
- The safest way to use this equipment is on water.
- You are responsible for yourself and others when using this product.
- Always use the safety system in case of an emergency.
- Always use the right kite size for your ability and wind conditions. Do not over estimate your abilities. Be aware that strong gusts can be life threatening.
- Never kite in stormy weather and strong gusts. The kite may attract lightning.
- Never kite when there are obstacles downwind of you.
- Never kite in off or on shore wind conditions.
- Never kite under the effect of drugs and alcohol.
- Never kite alone.
- Never kite without a safety system.
- Never tie yourself to the kite permanently. You should always be able to let go of the kite rapidly in a case of emergency.
- Do not try to grab a kite by its lines. Under tension, they can be as lethal as a razor blade.
- Do not use this kite as a flying device or a floating device.

MEANINGFUL TIPS FOR YOUR SAFETY AND THE SAFETY OF OTHERS:

1. Helmet, life vest and harness. It is highly recommended to wear a helmet, life vest and a harness when learning to kite and using this product. The harness should be comfortable and of strong manufacture.
2. Choose your practice spot carefully. The best spot for learning to use this product is an accredited kiteboarding school. When choosing a spot after taking kiteboarding lesson in an accredited kiteboarding school, look for:
 - The least crowded place (but do not kite alone).
 - Spot which is free of obstacles, such as houses, trees, electric lines, cars etc. Always consider enough room for error.
 - Shallow water with sideshore winds.
 - It is always good to have a safety boat near by.
3. Check for weather and wind conditions. Check with the local weather forecast. Look for the wind direction and speed, which might change during the day. You should not ride in stormy weather or strong gusts. The kite may attract lightning.
4. Respect other kites. Always look around you and pay attention to other kites. Do not hesitate to help others launch or land their kites. Never unwind your kite line on top of others'. Never land your kite on top of someone's lines, it may cause danger.
5. Respect people standing by. Always inform spectators about the power of the kite and the potential risk for them when staying downwind from a kite surfer.
6. Learn to use your safety system. Always check carefully before flying this kite, if the safety system is not worn out and works properly. Learn how to use the push away safety system. Never fly this kite without the safety system, which allows you to kill rapidly the power of the kite. Use a safety leash which connects you to the kite. This leash should also be releasable for cases of emergency.

SAFETY SYSTEM

THESE STEPS CLEARLY EXPLAIN YOU HOW THE PUSH AWAY SAFETY SYSTEM WORKS. IT IS SIMPLE AND SAFE. FOLLOW THESE STEPS EVERY TIME BEFORE RIDING, BECAUSE THE SAFETY SYSTEM CAN GET WORN OUT AND MAY NOT WORK PROPERLY. SO, CHECK CAREFULLY IF THE SAFETY SYSTEM IS WORKING BEFORE EVERY RIDING SESSION.



BAR

1. Depower line
2. Elastic bar ends
3. Smart stopper
4. Push away safety system
5. Releasable chicken loop



SAFETY SYSTEM

6. Red plastic part
7. White bottom part
8. Safety line
9. Metal end loop
10. Safety leash



HOW TO USE
THE SAFETY SYSTEM



HOW TO
ATTACH THE LINES




HOW TO
ROLL THE BAR



1. Always attach your kite with your safety leash to your harness.



2. In case of an emergency, simply push away the red plastic part of the quick release with CF logo.



3. This releases the metal end loop of the chicken loop.



4. Now the chicken loop is opened. This kills rapidly the power of the kite. You are now connected to the kite only via the safety leash, which should also be releasable in a case of extreme emergency.



5. To re-assemble the safety system, hold the white bottom part of the quick release in your left hand and push the metal end of the chicken loop by your right hand to the hole in the quick release.



6. This pushes the red part of the quick release up and allows the metal loop to automatically click back into its original position. Now the quick release safety system is ready to use again.

MAKE SURE THAT THERE IS NO SAND OR DIRT INSIDE THE SAFETY SYSTEM. RINSE THE SAFETY SYSTEM WITH CLEAN WATER AFTER EVERY RIDE IF POSSIBLE.



The most important thing of all in the warranty section is that **you have to register your kite online on:**

WWW.CRAZYFLYKITES.COM/REGISTER

By registering, you increase the speed of handling the warranty issue and ensure your warranty rights.

CrazyFly warrants this product to be free of major material or production defects to the original purchase for a 1 year period from the date of purchase.



CRAZYFLY LIMITED WARRANTY:

This warranty is valid only if the product is used for recreation and excludes products used in teaching or rental operations.

CrazyFly will make the final warranty decisions, after careful inspection of photos of the damaged equipment which have to display the serial number of the kite as well. This product can be returned if the authorization by CrazyFly is given to you. If CrazyFly gives the authorization to return the product, the customer is responsible to prepay all the shipping costs and insure the package. Shipping charges are not refundable. CrazyFly is responsible for return shipping and insurance costs to the customer. All coverage under this warranty is void if any modification or change has been made to this product. Repaired or replaced products are covered only for the remainder of the original warranty. All warranty claims must be accompanied by the original purchase receipt, which has to clearly state the name of the retailer, item name and the date of purchase.

COVERED BY CRAZYFLY LIMITED WARRANTY:

- Any manufacturer's defect as determined by CrazyFly.

NOT COVERED BY CRAZYFLY LIMITED WARRANTY:

- Any problems resulting from misuse, abuse, impact on any surface including water.
- Any problems resulting from excessive sun exposure or winds on the beach, such as discolored graphics.
- Damage due to improper storage and handling of the kite.
- Damage due to excess inflation.
- Damage caused by any modifications, or defacing the serial number.
- Damage from rigging with any other components other than CrazyFly.
- Damage caused by pilot error.
- Normal wear and tear.
- Tears in the canopy.
- Kite lines.
- Bladders.
- Damage caused by anything other than defects in the material or workmanship.

MEANINGFUL TIPS FOR SHIPPING THE KITE IF REQUIRED:

- Send the kite only. Do not send the bar and lines.
- Do not send the kite in its original protection bag. Use a firm box instead for shipping.
- Use masking tape to point out the kite's problem.

FOR ALL WARRANTY CLAIMS, CONTACT YOUR NEAREST CRAZYFLY RETAILER.

RETAILER STAMP:

DATE OF PURCHASE:

SERIAL NUMBER:

